



Positioning Jigs



Remove the tripod from welding gun , then replace with the positioning jig.



Main body of Positioning jig		
SGR-40		
Adaptors of Positioning jig		Stud dia.
SGA-20-6		Up to M6
SGA-25-6		Up to M6
SGA-25-8		M8 - M10
SGA-30-6		Up to M6
SGA-30-8		M8 - M10

Spatter remover



Easy removal of welding spatter around the stud.
Use the electric drill set.

Stud dia.	Part No.
M3	M3-S
M4	M4-S
M5	M5-S
M6	M6-S

